

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
F. Algodao (6-18%)		0454	1679	1179	0697	1925	2070	1806	0186	1054	06.02.05	Customer Calibration
Ackerbohne (5-35%)		1253	1808	1128	2186	2455	1899	3505	1750	1104	03.17.04	djEurope-Austria
Acucar, (Sugar) (0-5%)		1063	0202	0000	0000	3045	2070	0500	0143	1054	03.10.05	Brazil
Alfafa (6-17%)		0108	0054	1009	0000	0675	2070	1706	0114	1054	03.11.05	Brazil
Algodao Caroco (3-9%)		0041	0351	1005	0000	0795	0070	0903	0196	1054	06.03.05	Customer Calibration
Amaranth <Amaranto>		1004	0140	0000	0000	2770	2070	1811	1595	1064	11.24.82	Argentina
Barley	CO322	0718	1082	1130	0000	2115	1550	2011	0378	1074	05.12.95	GMT II Canada
Barley (10-25%)		1033	3062	1210	2413	2035	1550	2510	0343	1050	09.11.03	Brazil
Barley (8 - 29%)		0407	1942	1227	2065	2115	1550	2908	0334	1074	06.25.92	Canada
Barley <Gerst>/<Orge>		0176	3235	1257	2510	2255	1550	2508	0523	1094	07.10.95	Flemish / djEurope France
Barley <Gerste>		0333	3220	1273	2420	2255	1550	2508	0554	1094	03.18.91	djEurope-Germany
Barley <Orzo>		0316	3220	1273	2432	2255	1550	3508	0549	1094	03.18.91	djEurope-Italy
Barley <W. Gerste>		1205	3585	1268	4066	2035	1550	2508	1065	1094	03.23.05	djEurope-Austria
Barley, (California)		0392	1942	1227	2065	2255	1550	2908	0309	1074	03.17.83	
Barley, Flaked	CO269	0613	1086	1096	0000	1555	1499	1711	0336	1074	07.18.91	Customer Calibration
Barley, Hull-less (preliminary)		0194	1724	1187	0947	2445	1658	2005	0338	1046	06.29.05	Customer Calibration
Barley, Malted Distiller Malt		2254	1363	1194	0000	1485	1550	1004	1422	1074	08.02.83	Preliminary Constants 1984
Barley, Six Rowed (6-22%)	070327N	0377	1874	1212	0999	2105	1860	2206	9954	1056	08.01.07	NTEP
Barley, Spring (8-25%)		0165	3235	1257	2510	2255	1550	2508	0415	1014	04.03.97	djEurope-Austria
Barley, Two & Six Rowed <Cebada>		0394	1942	1227	2065	2255	1550	2408	0312	1074	12.21.94	Argentina
Barley, Two Rowed (6-20%)	080324N	0006	3427	1261	2776	2105	1079	2006	9906	1056	05.01.08	NTEP
Barley, Winter (8-25%)		0178	1902	1195	2120	2035	1550	2508	1041	1094	03.17.04	djEurope-Austria
Barley, Winter <Escourgeon><Gerste Winter>		0190	1902	1195	2120	2035	1550	2508	1029	1094	05.01.91	djEurope-France/Flemish
Barley, Winter <Gerste Winter>		0184	1902	1195	2120	2055	1550	2508	1015	1094	03.18.91	djEurope-Germany
Beans, Baby Lima (8-18%)	990415	1393	3057	1151	2506	2555	2073	1808	0347	1109	08.01.07	Non-NTEP
Beans, Black (8-20%)	990415	1673	5429	1352	6177	2605	1097	2008	2304	1077	08.01.07	Non-NTEP
Beans, Black (8-29%)	CO297	1109	0661	0091	1502	2425	1899	2908	1230	1104	11.16.92	GMTII Brazil
Beans, Black Turtle	CO220	1688	3785	1242	4466	2555	1899	2208	0221	1104	10.10.88	Customer Calibration
Beans, Blackeye (8-18%)	010409	0236	1323	1103	0420	2395	2068	1808	0310	1088	08.01.07	Non-NTEP
Beans, Cranberry (8-20%)	010409	1814	3995	1256	4738	2385	1087	2008	0370	1119	08.01.07	Non-NTEP
Beans, Garbanzo (6-18%)	060308	3212	5646	1327	6661	2565	2080	1806	0305	1109	08.01.07	Non-NTEP
Beans, Great Northern (8-20%)	060322	1557	3103	1139	2632	2425	1876	2008	2438	1098	08.01.07	Non-NTEP
Beans, Kidney (8-20%)	010418	1359	3101	1159	2538	2335	1280	2008	1802	1109	08.01.07	Non-NTEP
Beans, Large Lima (9-15%)	010411	1125	1492	1081	0749	2275	2085	1509	0377	1149	08.01.07	Non-NTEP
Beans, Light Red Kidney		1845	3627	1192	4344	2305	1899	2408	1829	1104	09.27.88	Customer Calibration
Beans, Pea (8-20%)	990406	1139	3109	1190	2457	2675	1086	2008	2150	1077	08.01.07	Non-NTEP
Beans, Pink (8-20%)	030320	1356	1960	1139	2385	2455	1873	2008	1814	1108	08.01.07	Non-NTEP
Beans, Pinto (8-18%)	990326	3390	5752	1317	6836	2445	2073	1808	2073	1098	08.01.07	Non-NTEP
Beans, Small Red (8-18%)	030320	1854	5307	1304	6101	2505	1089	1808	1863	1098	08.01.07	Non-NTEP
Beans, Small White (8-20%)	990406	1139	3109	1190	2457	2675	1086	2008	2150	1077	08.01.07	Non-NTEP
Beans, Yelloweye (10-18%)	030404	1392	3024	1149	2482	2455	1881	1810	1095	1108	04.04.03	Non-NTEP GAC 2100 2006
Bird Seed	CO212	0576	3244	1300	2317	2170	2060	2108	1853	1064	07.27.88	Customer Calibration
Brazil Feed Grain (13-30%)		1199	1760	1122	2089	2105	2070	3013	1786	1054	02.10.05	Customer Calibration
Buckwheat		0724	1923	1267	0931	2100	2070	2108	1593	1104	12.24.81	Preliminary Constants 1984
Buckwheat <Ble Noir>		0688	1394	1188	0378	2305	1570	2508	1440	1064	05.19.92	djEurope-France
Bulgarwheat		1111	0291	0005	0000	2085	2068	1508	1431	1064	06.07.83	Preliminary Constants 1984
Camerao (2-30%)		0051	0171	1012	0000	1955	1084	3002	1080	1406	12.06.05	Brazil
Canola	CO322	0014	1425	1084	0582	2201	1380	2105	1441	1014	05.15.95	GMT II Canada
Canola		0096	1229	1062	0329	2201	1380	2104	1435	1014	06.17.96	Canada

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Canola (4-15%)	990426	0013	1425	1084	0582	2201	1369	1504	2242	1024	08.01.07	Non-NTEP
Canola Meal (10-18%)		0016	0212	0000	0000	1700	2070	1810	1808	1054	12.30.03	Customer Calibration
Carrot		1456	3121	1142	2575	1805	1550	2004	0351	1004	07.16.92	djEurope-France
Casca de Sojal (6-18%)		0216	1449	1101	0508	1255	0070	1806	0123	1054	06.02.05	Brazil
Cat Litter Clay		1048	1213	1034	0295	2560	2580	1001	1401	1104	09.22.82	Preliminary Constants 1984
Cattle Bran <Gado Farelo> (8-29%)		0078	0014	1022	0103	1865	2070	2908	0152	1054	10.25.04	Brazil
Chick Feed F-1		1020	0178	0000	0000	1970	1070	1505	0885	1054	09.22.03	Customer Calibration
Chick Feed F-1 Harina		1068	0231	0000	0000	2039	2099	1205	1768	1054	10.06.03	Customer Calibration
Chick Feed F-2 Harina		1236	0451	0000	0000	2105	2099	1306	1704	1057	10.03.03	Customer Calibration
Chick Feed F-2 Pellet		1280	0599	0000	0000	1965	2099	1305	1757	1054	10.06.03	Customer Calibration
Chick Feed F-O Pellet		0394	1063	1064	0000	2010	2070	1206	1792	1054	10.06.03	Customer Calibration
Chicory		1942	3311	1120	4009	1555	1550	2505	1081	1004	07.16.00	djEurope-France
Coffee	CO281	0128	0071	1011	0000	1715	2080	1511	1587	1064	02.26.92	Customer Calibration
Coffee (8-15%)		3754	5408	1217	6604	2105	2080	1508	1565	1064	04.28.03	Customer Calibration
Coffee Tex Blend 2 (9-35%)		1055	1246	1052	0450	2100	2080	3509	1859	1064	12.03.03	Customer Calibration
Coffee Whole Green Bean (3-12%)		0747	1158	1124	0000	1800	2599	1503	1845	1064	06.16.05	Customer Calibration
Coffee, Bean	CO158	3860	5518	1229	6819	1700	2080	2010	1817	1064	10.14.87	Uganda
Coffee, Columbia & JCS (8-30%)		1234	1956	1146	3299	2500	1084	2006	0585	1054	10.14.86	Etats-Unis
Coffee, Columbian (Roasted) (8-15%)		0268	0024	1044	0000	2105	2080	1508	1569	1064	04.28.03	Customer Calibration
Coffee, Green Beans (5-15%)		0333	1012	1054	0000	2105	2080	1505	1598	1064	05.30.03	Customer Calibration
Coffee, Pre-Dried Green Beans (3-8%)		0065	0265	1027	0000	2135	2080	0803	1530	1064	05.30.03	Customer Calibration
Coffee, Roast	CO153	0919	1557	1122	0000	1155	2080	0803	1556	1064	09.08.86	Customer Calibration
Coffee, Tchibo (3-18%)		1808	3773	1217	0710	1605	2099	1600	1344	1054	02.17.93	Etats-Unis
Coffee, Whole Green Bean (3-12%)		2126	1395	1180	0000	1800	2599	1203	1860	1064	06.16.05	Customer Calibration
Coffee,JIM & SKW (8-30%)		1170	3027	1168	0859	1805	2099	2501	1404	1054	10.14.86	Etats-Unis
Corn (8-20%)	050208N	1783	7205	1488	8155	2305	2553	2008	9910	1087		Official GAC 2100 2006
Corn (8-28%)	070330N	0218	1739	1190	0952	2305	2853	2808	9976	1087	08.01.07	NTEP
Corn (8-35%)		0466	0044	1097	0000	2355	2070	3508	0059	1054	05.06.02	djEurope-France
Corn (8-45%)		0466	0044	1097	0000	2355	2070	4508	0049	1054	03.17.04	djEurope-Austria
Corn <Maiiz>		1397	5112	1347	4756	2305	2568	2210	0082	1074	05.19.95	Argentina
Corn <Mais Waxy>		0201	1423	1140	0624	2355	2070	3313	0056	1054	05.01.94	djEurope-France
Corn <Mais, Zonder Waxy>		0466	0044	1097	0000	2355	2070	4508	0049	1054	07.10.95	Flemish
Corn <Mais>		0331	0085	1070	0000	2306	2580	4508	0054	1104	03.18.91	djEurope-Italy
Corn <Milho Baixa Umidade> (8-24%)	CO297	1132	0261	0012	0000	2305	2580	2408	0088	1074	11.16.92	GMTII Brazil
Corn Beans (15-32%)		0502	0006	1099	0000	2200	2070	3215	1793	1054	09.24.04	Brazil
Corn Meal (9-15%)		1904	0788	0132	0000	1600	2060	1509	1703	1054	03.31.04	Customer Calibration
Corn Sweet (30-65%)		0067	0236	1023	0008	1785	0753	6030	0159	1087	02.27.06	Customer Calibration
Corn, BD correction for Canada		0186	0106	1041	0009	2365	2580	2210	0015	1051		
Corn, Dry <Mais, Strocken>		0332	1189	1110	0287	2305	2080	2010	0830	1004	03.18.91	djEurope-Germany
Corn, Flaked		1260	1568	1099	2050	1275	2580	2210	1756	1104	02.02.82	Preliminary Constants 1984
Corn, Flaked Steamed (9-35%)		1011	0311	0000	0000	1555	2580	1812	1783	1104	10.15.03	Customer Calibration
Corn, Grits		2233	1265	1235	0000	2160	2060	1412	1807	1054	11.21.78	Customer Calibration
Corn, High Moisture (13-30%)		0722	1108	1146	0041	2305	2553	3013	0063	1087	09.15.03	Customer Calibration
Corn, High Moisture (19-40%)	050105N	0154	0180	1027	1059	2305	2553	4019	9952	1087	05.01.05	Official GAC 2100 2006
Corn, High Moisture (22-40%)		1498	1481	1036	0912	2305	2580	3622	0006	1074	04.28.04	Canada
Corn, High Moisture (27-40%)	070330N	0964	1062	1236	1001	2305	2853	4027	9979	1087	09.01.07	NTEP
Corn, High Moisture <Mais, Feucht>		0365	0069	1074	0000	2355	2070	4508	0049	1054	03.18.91	djEurope-Germany
Corn, High Moisture <Maiz, Alta Hum>		0152	0191	1030	1060	2305	2562	4021	0040	1074	03.28.94	Argentina
Corn, High Moisture <Milho Alta Umidade> (7-35%)		0190	1036	1063	0146	2305	2580	3507	0039	1074	07.22.94	GMTII Brazil
Corn, High Moisture <Milho Brasil> (8-40%)		0181	0250	1018	1146	2305	2580	4008	0071	1074	03.27.96	Brazil

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Corn, High Moisture modified range (10-40%)		1026	0188	0000	0000	2305	2553	4510	0072	1087	05.25.06	Bangkok, Thailand
Corn, High Oil (6-30%)	990442	0437	1699	1211	0815	2305	2560	3006	1988	1087	08.01.07	Non-NTEP
Corn, High Test Weight	CO159	0014	3788	1345	4218	2505	2580	2210	0016	1104	10.15.87	Low corn calibration for highest test weight samples
Corn, Low	CO216	1395	5112	1347	4756	2305	2580	2210	0239	1104	11.03.88	Customer Calibration
Corn, Low Moisture	CO288	1414	5089	1347	4756	2305	2580	2112	0075	1074	06.02.92	New Zealand
Corn, Low Moisture	CO322	1149	7043	1546	6733	2305	2580	2110	0073	1074	05.15.95	GMT II Canada
Corn, Low Moisture (10-21%)		1395	5112	1347	4756	2305	2580	2110	0073	1074	06.25.92	Canada
Corn, Meal	Special	1894	0788	0132	0000	1600	2060	1309	1716	1054	11.21.78	Customer Calibration
Corn, Rolled (10-22%)		1270	1568	1099	2050	1275	2580	2210	1755	1104	03.13.06	Customer Calibration
Corn, Sweet (13-33%)		0201	1423	1140	1028	2090	1570	1806	1294	1054	05.01.94	djEurope-France
Corn, Sweet (6-12%)		0307	0045	1053	0000	1915	2560	1206	1600	1074	06.16.06	Customer Calibration
Corn, Sweet Seed	CO298	0362	0002	1056	0000	1660	2060	1510	1641	1074	01.12.93	
Corn, Waxy <Mais, Sauf waxy> (8-35%)		0466	0044	1097	0000	2355	2070	3508	0059	1054	05.01.91	djEurope-France
Corn, Waxy <Mais, Waxy>		0201	1423	1140	0624	2355	2070	3313	0056	1054	05.01.94	djEurope-France
Cotton Seed (2-10%)		0770	0063	1107	0174	2305	1550	1903	1495	1004	01.29.98	djEurope-France
Cotton Seed Meal (6-19%)		3848	5369	1199	6627	1885	2070	1609	1844	1054	03.16.06	Customer Calibration
Crave Core		0534	1068	1092	0000	2010	1562	1302	1604	1064		Customer Calibration
Dog Food		1005	0269	0000	0000	1105	2065	1605	0370	1064	10.12.89	Customer Calibration
Dog Food		1009	0277	0000	0000	1005	2065	2406	0251	1064	10.12.89	Customer Calibration
Dog Food		0623	1080	1089	0000	0905	2065	2506	0132	1064	10.12.89	Customer Calibration
Erwten		0170	0123	1034	0000	2342	2068	2512	1824	1074	07.10.95	Flemish
Extruded Feed (5-15%)		1043	0277	0000	0000	1860	2070	1505	1754	1054	03.30.04	Brazil
Extrusada (5-15%)		1153	0497	0000	0000	1860	2070	1505	1721	1054	03.31.04	Brazil
Extrusado Veg. Alfapreme (3-14%)		0312	1549	1135	0590	1435	2070	1403	0114	1054	03.09.05	Brazil
F. Algodao (6-18%)		0454	1679	1179	0697	1925	2070	1806	0186	1054	03.09.05	Brazil
F. Soja Integral (7-14%)		0236	1208	1068	0222	1535	0663	1407	0037	1107	06.07.05	Brazil
Farela Diversos (5-20%)		0060	0080	0000	0000	1865	2070	2005	0152	1054	09.07.04	Brazil
Farelo De Cacau (3-17%)		1510	1501	1032	0861	1375	2070	1703	0140	1054	03.08.05	Brazil
Farelo De Soja (5-18%)		0112	3231	1220	2429	1425	2070	1805	0177	1054	03.07.05	Brazil
Feed Grains Nutripeixe AL 45 (2-20%)		1062	0350	0000	0000	1705	1084	2002	1062	1406	03.30.05	Customer Calibration
Feed Grains Nutripeixe SI Engorda (2-20%)		0026	0201	0000	0000	1225	1084	2002	1043	1405	02.17.05	Customer Calibration
Feed Grains Nutripeixe TR 28 (2-20%)		1096	0589	0000	0000	1225	1084	2002	1072	1406	03.30.05	Customer Calibration
Feed Grains Nutripeixe TR 36 (2-10%)		0996	1430	1145	0000	1480	1084	1002	1020	1406	03.31.05	Customer Calibration
Feed Grains Purina Labina E (2-20%)		1379	0858	0000	0000	1785	1084	2002	1049	1406	03.29.05	Customer Calibration
Feed Ground Commodity (10-17%)		0056	0190	1018	0000	2165	2553	1710	1708	1054	02.01.05	Customer Calibration
Feed Starter Feed (9-15%)		0146	0092	1021	0000	1935	2553	1509	0032	1087	02.01.05	Customer Calibration
Feed, combined (5-20%)		1016	0222	0000	0000	1865	2070	2005	0142	1054	10.01.04	Brazil
Feed, Purified	CO149	0617	1332	1075	0000	0640	0010	0903	1892	1014	07.15.86	Customer Calibration
Fei, Jao (8-32%)	CO297	1395	0317	0070	1003	2425	1899	3208	1211	1104	11.16.92	GMTII Brazil
Fescue		0262	0063	1027	0000	0850	3040	2409	1838	1064	04.18.83	
Filberts	CO178	3375	3364	1088	4261	1705	1899	1001	1689	1084	05.21.87	Customer Calibration
Finished Feed (10-18%)		0109	0109	1014	0000	1955	2553	1810	0034	1087	02.04.05	Customer Calibration
Flaxseed (5-15%)	000411	0114	1394	1090	0501	2255	1557	1505	1202	1034	08.01.07	Non-NTEP
Flaxseed <Leinsamen> (6-23%)		1046	1032	0000	0146	1790	1590	2306	1233	1014	03.17.04	djEurope-Austria
Green Coffee (5-12%)	AL003	0277	0063	1051	0000	2055	0880	1205	1583	1064	12.17.04	Customer Calibration
Groats (5-13%)	CO428	0334	0076	1076	0000	2320	1547	1305	1628	1024	11.13.00	Customer Calibration
Groats, Green (5-13%)	CO428	0352	0076	1076	0000	2320	1647	1305	0327	1074	11.13.00	Customer Calibration
Haver		1062	1705	1120	0980	1584	1550	2508	1149	1074	07.10.95	Flemish
Horsebean <Feverole>		0325	1277	1124	0398	2342	2068	2707	1684	1104	05.01.91	djEurope-France

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Koolzaad		1262	1894	1129	2222	2241	1380	2306	0759	1024	07.10.95	Flemish
L. Equinos (9-23%)		0110	0102	1011	0000	1865	2070	2309	0150	1054	10.25.04	Brazil
L. Gado P. (2-26%)		0055	0101	0000	0000	1865	2070	2602	0528	1054	10.25.04	Brazil
Laminados (8-22%)		0406	0021	1068	0000	1595	2070	2208	0151	1054	10.25.04	Brazil
Lentils (7-15%)	000417	0661	1093	1122	0002	2505	2075	1507	1096	1087	08.01.07	Non-NTEP
Linha Pelletizada Diversos (5-20%)		0037	0132	0000	0000	1795	2070	2005	1777	1054	08.11.04	Brazil
Linha Triturada (5-22%)		0036	0132	0000	0000	1675	2070	2205	1797	1054	08.12.04	Brazil
Linseed <Lin Fibre>		1046	1032	0000	0146	1790	1590	2306	1233	1014	05.01.91	djEurope-France
Linseed, Oil Type <Lin Oleagineax>		0245	0036	1035	1028	2090	1570	1806	1294	1054	05.01.94	djEurope-France
Linsen (9-20%)		0298	1827	1205	0984	2605	1550	2009	1863	1084	03.17.04	djEurope-Austria
Lupin		1142	1912	1148	2249	2342	2068	2508	1486	1144	10.09.92	djEurope-France
Lupins	CO187	1552	3173	1162	2747	2325	1899	1607	0033	1105	09.14.87	
Macaroni	CO242	0378	0259	1036	1250	1705	3050	2608	0124	1034	01.25.90	Customer Calibration
Maize <Milho Extrusado> (8-19%)		0288	0094	1052	0000	1865	2070	1908	0144	1054	11.02.04	Brazil
Maize <Milho Germen> (7-14%)		1418	0860	0000	0000	1885	2070	1407	0176	1054	06.01.05	Brazil
Maize <Pellets C. / Milho Laminado> (8-27%)		0090	0098	1006	0000	1865	2070	2708	0178	1054	10.26.04	Brazil
Maize <Pellets Milho> (5-20%)		0015	0155	0000	0000	2105	2070	2005	1762	1054	04.04.01	Brazil
Maize, Africa	CO175	1400	5112	1347	4756	2305	2580	2210	0035	1104	04.21.87	Customer Calibration
Maize, Plated <Milho Laminado> (10-25%)		1026	0300	0000	0000	1635	2580	2510	1793	1104	04.01.04	Brazil
Meat Flour <Farinha de Carne> (3-19%)		1692	3858	1226	4460	2385	2070	1903	0124	1054	11.04.05	Brazil
Meat Meal 3-13%	CO437	0117	0155	1020	0000	1905	1899	1303	1585	1084	01.24.02	Customer Calibration
Millet	CO293	0144	3326	1264	2604	2360	2070	1809	1556	1064	08.17.92	Customer Calibration
Millet (5-22%)		0653	3909	1451	2860	1705	1550	2003	1265	1004	06.19.93	djEurope-Italy
Millet (8-20%)		0382	3599	1335	2804	2360	2070	2008	1566	1064	05.22.96	DJ Calibration extended Data Range With Nebraska Data
Millet (Siberian/German) (8-20%)		0393	3703	1357	2925	2360	2070	2008	1505	1064	10.06.04	
Millet <Mi Jo>		0393	3703	1357	2925	2360	2070	2011	1502	1064	02.16.93	Argentina
Milo (11-20%)		0393	3703	1357	2222	2241	1380	2306	0759	1024	02.16.93	djEurope-France
Milo (California)		0730	1696	1243	0682	2405	2057	2605	1042	1064	03.17.83	
Milo <Sorgo> (10-25%)		0447	3011	1266	2167	2405	2057	2510	1092	1044	11.16.92	Brazil
Milo extended for reference only (25-41%)		2174	1140	1278	0009	2460	4060	4125	0005	1045	09.29.05	
Milo, Fat taken away <Milo Desengordurado> (8-14%)		1445	0814	0000	0000	1960	0370	1408	0135	1054	05.11.05	Customer Calibration
Milo, Flaked	CO142	0878	1165	1138	0000	1085	2057	2416	1068	1044	06.11.86	Customer Calibration
Milo, High Moisture (15-41%)		0620	1019	1137	0000	2605	1065	4115	1025	1045	08.26.05	Customer Calibration
Milo, Nebraska		0866	3106	1331	2092	2405	2057	2108	1089	1044	08.31.84	Dj calibration constants chart, Issued 30Oct.91
Milo, Plated <Milo Laminados> (10-22%)		0264	0041	1038	0000	1861	2070	2210	0134	1054	10.25.04	Brazil
Minerals (0-10%)		0184	1565	1129	0605	2840	0063	1000	0133	1054	06.08.05	Customer Calibration
Mustard Seed, Brown (5-14%)	030324	3216	3749	1171	4629	2355	1573	1405	1035	1024	08.01.07	Non-NTEP
Mustard Seed, Oriental (5-14%)	030324	3219	3749	1171	4629	2355	1573	1405	1022	1034	08.01.07	Non-NTEP
Mustard Seed, Yellow (5-14%)	030324	3213	3749	1171	4629	2355	1573	1405	1028	1034	30324	Non-NTEP
Mustard Seed, Yellow (5-14%)		3213	3749	1171	4629	2355	1573	1405	1028	1034	03.24.03	Non-NTEP GAC 2100 2006
Nut, Meats	CO234	1699	1703	1046	2174	1405	0000	2203	1055	1050	08.06.89	Customer Calibration
Nutripeixe Al45 (2-8%)		5449	7143	1244	8673	1865	2070	0802	0175	1054	11.05.04	Brazil
Nutripeixe SI (6-11%)		1469	2803	0000	0000	1245	2070	1106	0112	1054	11.03.04	Brazil
Nutripeixe SI Cresc. (8-10%)		0001	0279	0000	0000	1255	2070	1008	0133	1054	11.03.04	Brazil
Nutripeixe SI Engorda (2nd group of Nutr)(6-11%)		1466	2803	0000	0000	1245	2070	1106	0115	1054	11.05.04	Brazil
Nutripeixe SI Terminacao (8-11%)		0131	0177	1019	0000	1295	2070	1108	0135	1054	11.05.04	Brazil
Nutripeixe TC40 (9-11%)		1086	0449	0000	0000	1415	2070	1109	0112	0054	11.05.04	Brazil
Nutripeixe TR32 (4mm) (5-12%)		0294	0081	1045	0000	1435	2070	1205	0102	1054	11.03.04	Brazil
Nutripeixe TR32 (8mm) (9-12%)		0298	0040	1042	0000	1355	2070	1209	0119	1054	11.08.04	Brazil

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>	<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Nutripeixe TR36 (2-7%)	0532	0135	1091	0000	1475	2070	0702	0128	1054	11.08.04	Brazil
Oat (8-25%)	1062	1705	1120	0000	2342	2068	2512	1718	1074	05.01.91	France
Oats (8-18%)	5653	7223	1264	8999	1705	1648	1808	9928	1038	08.01.07	NTEP
Oats (8-20%)	0798	1148	1133	0000	1805	1570	2008	0621	1074	06.14.96	GMT II Canada
Oats (8-25%)	1026	1517	1105	0790	1805	1570	2508	0643	1074	06.25.92	Canada
Oats (8-25%)	1063	1705	1120	0980	1584	1550	2508	1148	1074	03.17.04	djEurope-Austria
Oats (9-25%)	1121	1467	1072	0719	1215	1570	2509	0616	1056	09.11.03	Brazil
Oats <Avena>	1325	3085	1152	2520	1515	1550	2907	1168	1074	03.18.91	djEurope-Italy
Oats <Aveia> (9-25%)	1103	1467	1072	0719	1215	1570	2509	0616	1074	11.16.92	GMTII Brazil
Oats <Avena>	1016	1517	1105	0790	1605	1570	2108	0659	1074	12.21.94	Argentina
Oats <Avoine>	1062	1705	1120	0980	1584	1550	2508	1149	1074	05.01.91	djEurope-France
Oats <Hafer>	1055	1705	1120	0980	1584	1550	2508	1156	1074	03.18.91	djEurope-Germany
Oats, <Aveia Lam.> -2 (5-11%)	1084	0662	1014	0000	1180	0090	1105	0107	1054	06.03.05	Brazil
Oats, Groats	0227	0157	1061	0000	2375	1570	1506	0603	1074	06.27.86	Customer Calibration
Oats, Plated <Aveia Laminada> (4-15%)	3236	3656	1131	4469	1125	2070	1504	0130	1054	03.26.05	Brazil
Oats, Plated <Aveia Laminada> (5-28%)	0074	0075	0000	0000	1225	1084	2805	0319	1406	04.04.04	Brazil
Onion (5-18%)	1056	1600	1108	0980	1584	1550	2508	1149	1074	02.12.98	djEurope-France
Onion (5-20%)	1318	1797	1112	0862	2342	2068	2508	0282	1074	01.01.92	djEurope-France
Origem Animal (5-10%)	0407	3160	1234	2252	1815	2070	1005	0130	1054	05.02.05	Brazil
Paardebonen	0325	1277	1124	0398	2342	2068	2707	1684	1104	07.10.95	Flemish
Particula Atletica (8-14%)	1006	0193	0000	0000	1865	2070	1408	0185	1054	11.02.04	Brazil
Pasta (shells) (5-22%)	1941	3053	1114	2891	1245	3050	2205	0159	1034	04.26.06	Customer Calibration
Peanut	1140	1381	1058	0601	2045	1899	2004	1223	1084	12.15.92	Brazil
Peanut (5-30%)	1403	1773	1089	4292	2405	2057	2408	1090	1044	05.14.85	Etats-Unis
Peanut Bran <Farelo de Amendoin> (4-18%)	1331	0942	0000	0000	2120	0063	0804	0179	1054	06.07.05	Brazil
Peanut, Combined (4-12%)	1139	1474	1072	0700	2005	1899	1204	0373	1084	08.17.01	Customer Calibration
Peanut, Runner (4-12%)	1124	1361	1056	0569	2005	1899	1204	0351	1084	08.17.01	Customer Calibration
Peanut, Spanish (4-12%)	1114	1412	1064	0621	2005	1899	1204	0348	1084	08.17.01	Customer Calibration
Peanut, Spanish (4-40%)	1006	0104	1002	0033	1905	1899	4004	1298	1084	03.01.05	Customer Calibration
Peanut, Valencia (4-51%)	0064	0110	1009	0002	1905	1899	5104	1257	1084	02.24.05	Customer Calibration
Peanut, Virginia (4-43%)	0041	0128	1005	0000	1805	1899	4304	1277	1084	02.24.05	Customer Calibration
Peanuts	1403	1773	1089	2146	1905	1899	3005	1200	1084	05.14.85	Per Calibration Bulletin 850801-1
Peanuts <Mani, Valencia>	1399	1773	1089	2146	1905	1899	3005	1205	1084	04.14.90	Argentina
Peanuts <Mani, Virginia>	1401	1773	1089	2146	1905	1899	3005	1202	1084	07.27.92	Argentina
Peanuts, Extra Large Runner	0342	1016	1053	0000	1835	1899	0803	1531	1084	12.28.90	Customer Calibration
Peanuts, Extra Large/Medium	0343	1016	1053	0000	1835	1899	0803	1530	1084	06.13.91	
Peanuts, Jumbo	1407	1773	1089	2146	1905	1899	1303	1413	1084	04.08.87	Customer Calibration
Peanuts, Jumbo	3787	3956	1138	6109	1905	1899	0702	1261	1084	06.13.91	Customer Calibration
Peanuts, Jumbo Runner	3787	3956	1138	6109	1905	1899	0702	1261	1084	12.28.90	Customer Calibration
Peanuts, Medium Runner	0340	1016	1053	0000	1915	1899	0804	1452	1084	12.28.90	Customer Calibration
Peanuts, Runner (4-40%)	0026	0124	1002	0000	1805	1899	4004	1202	1084	06.06.03	Customer Calibration
Peanuts, SP/Run (5-30%)	1187	1362	1050	0603	1905	1899	3005	1231	1084	03.22.93	
Peanuts, Spanish Blanched	1232	0816	0000	0000	2005	1899	0601	1331	1084	03.18.87	Customer Calibration
Peanuts, Spanish Combined	1645	3300	1144	2820	2005	1899	1201	1297	1084	03.18.87	Customer Calibration
Peanuts, Spanish Raw	1301	1668	1081	0969	2005	1899	1204	1224	1084	03.18.87	Customer Calibration
Peanuts, Valencia (5-30%)	1399	1773	1089	2146	1905	1899	3005	1205	1084	07.14.92	
Peanuts, Virginia (5-30%)	1401	1773	1089	2146	1905	1899	3005	1202	1084	07.27.92	
Peanuts, Virginia Extra Large	1408	1773	1089	2146	1905	1899	1303	1511	1084	04.09.87	Customer Calibration

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Peas (12-25%)		0170	0123	1034	0000	2342	2068	2512	1824	1074	05.01.91	djEurope-France
Peas <Erbsen> (5-40%)		1829	3526	1189	4264	2455	1899	4005	1867	1104	03.17.04	djEurope-Austria
Peas <Ervilha>		1261	0819	0141	1625	2495	1899	3011	1664	1104	12.15.92	Brazil
Peas <Pois>		0170	0123	1034	0000	2342	2068	2512	1824	1074	05.01.91	djEurope-France
Peas, Austrian Winter (8-14%)	030326	1507	5589	1407	6316	2635	1884	1408	1097	1087	08.01.07	Non-NTEP
Peas, Austrian Winter (8-24%)		1507	5589	1407	6316	2635	1884	1408	1097	1087	03.26.03	Non-NTEP GAC 2100 2006
Peas, Fodder <Futtererbsen>		0170	0123	1034	0000	2342	2068	2612	1724	1074	03.18.91	djEurope-Germany
Peas, Smooth Dry (8-19%)	000425	1422	5251	1354	4884	2635	0894	1908	1603	1098	08.01.07	Non-NTEP
Peas, Split (8-14%)	030320	0231	0069	1048	0000	2805	1870	1408	1066	1066	08.01.07	Non-NTEP
Peas, Wrinkled Dry (6-12%)	030326	1893	5190	1282	4999	2445	1893	1206	0382	1068	05.01.08	Non-NTEP
Pecans	CO192	1938	1934	1058	2550	1285	2099	3002	1377	1054	11.04.87	Customer Calibration
Pecans (2-7%)	AL004	1019	0235	0001	0000	1150	0599	0702	1139	1054	03.03.05	Customer Calibration
Pinzingallo Amar		0657	1270	1180	0260	2650	2060	2606	1669	1074	01.04.92	Argentina
Pinzingallo BCO		0136	1431	1153	0668	2845	2060	2509	1648	1074	09.04.79	Argentina
Pissello Prot		1745	3490	1187	4172	2575	1899	4010	1561	1104	03.18.91	djEurope-Italy
Polpa Citrica (7-13%)		0033	0735	1057	0000	2220	2070	1307	0196	1054	06.01.05	Brazil
Popcorn (6-26%)	920104	0657	1270	1180	0260	2650	2060	2606	1669	1074	08.01.07	Non-NTEP
Popcorn, White		0136	1431	1153	0668	2845	2060	2509	1648	1074	09.04.79	
Popcorn, Yellow		0657	1270	1180	0260	2650	2060	2606	1669	1074	01.04.92	Customer Calibration
Potato, Hash Brown (3-13%)	CO439	3393	7107	1405	8284	2305	1899	1303	1526	1054	03.06.02	Customer Calibration
Primrose	CO238	1350	1546	1060	0907	1255	2070	2008	1670	1064	11.22.89	Canada
Protenose (5-25%)		1760	7602	1509	8455	1825	2070	2505	0109	1054	03.08.05	Brazil
Racao Farelada		0030	0145	0000	0000	1700	2070	2005	1766	1054	04.01.04	Brazil
Racao Laminado (10-25%)		0277	0093	1047	0000	1565	2580	2510	1774	1104	04.01.04	Brazil
Racao Triturada (5-20%)		0047	0112	0000	0000	1700	2070	2005	1782	1054	04.01.04	Brazil
Rapeseed		1174	1712	1109	0985	2201	1380	2105	1447	1014	04.22.87	Dj calibration constants chart, Issued 30Oct.91
Rapeseed (4-15%)	990426	0013	1425	1084	0582	2201	1369	1504	1450	1024	08.01.07	Non-NTEP
Rapeseed (6-23%)		1262	1894	1129	2222	2241	1380	2306	0759	1024	05.01.91	djEurope-France
Rapeseed / Canola <Colza / Canola>		0010	1425	1084	0582	2201	1380	2105	1445	1014	04.14.92	Argentina
Rapeseed <Raps>		1248	1894	1129	2222	2241	1380	2306	0773	1024	03.18.91	djEurope-Germany
Rapeseed <Raps> 5-16%		1173	1790	1121	2061	2241	1380	1605	0733	1024	03.17.04	djEurope-Austria
Rapeseed, Dried <Raps GetRocknet>		1221	3043	1159	2373	2261	1380	2302	0444	1024	03.18.91	djEurope-Germany
Refinazil (5-20%)		0529	1238	1122	0168	1960	0070	2005	0130	1054	06.07.05	Brazil
Refinazil (5-20%)		0299	3684	1342	2914	1965	2070	2005	0172	1054	03.11.05	Brazil
Rice <Arroz> (8-22%)	CO297	0432	1523	1166	0603	1900	2065	2208	0285	1064	11.16.92	Brazil
Rice, Amaro Paddy	CO187	1431	3674	1249	4245	2020	2065	2710	1006	1064	09.14.87	Customer Calibration
Rice, Argentina	CO231	1044	0209	1016	0000	2700	2065	1709	0250	1064	07.27.89	Customer Calibration
Rice, Brewers Milled (10-15%)	030417	0732	3804	1472	4000	2800	1054	1510	0295	1024	08.01.07	Non-NTEP
Rice, Brewers Milled Parboiled (10-14%)	030505	0429	1926	1244	2029	2800	1038	1410	0236	1024	08.01.07	Non-NTEP
Rice, Brown M-7	CO155	1015	0209	1016	0000	2700	2065	1712	0672	1064	09.30.86	Customer Calibration
Rice, Calmochi (California)	CO239	0048	0164	0000	0000	1805	3065	3012	1692	1064	10.13.89	
Rice, Calrose Milled	CO155	3284	0702	0209	0000	2740	2065	1809	0363	1064	09.30.86	Customer Calibration
Rice, Calrose Paddy	CO155	1393	3586	1243	4145	2000	2065	2710	1259	1064	09.30.86	Customer Calibration
Rice, FC Brown	CO171	1829	0968	0103	0000	1310	2065	1407	0222	1064	03.23.87	Customer Calibration

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Rice, Integral (12-17%)		1055	0209	1016	0000	2700	2065	1712	0672	1024	09.11.03	Brazil
Rice, LG		0085	3098	1215	2376	1900	2065	2508	0203	1064	03.30.83	
Rice, LG (8-26%)	CO432	2421	0418	1132	1836	1780	2047	2608	0224	1057	09.10.01	Customer Calibration
Rice, LG <Arroz Gr Largo>		0085	3098	1215	2376	1900	2065	2510	0201	1064	12.21.94	Argentina
Rice, LG Brown (10-21%)	990527	2370	1626	1337	0400	2410	1073	2110	0251	1055	08.01.07	Non-NTEP
Rice, LG Brown Parboiled (10-14%)	010521	1623	0465	0087	0001	2500	2065	1410	0259	1054	05.21.01	Non-NTEP
Rice, LG Milled (10-20%)	990721	1764	0484	0121	0001	2630	1057	2010	0342	1055	08.01.07	Non-NTEP
Rice, LG Milled Parboiled (8-20%)	020326	1470	0411	0058	0001	2460	1085	2008	0223	1055	08.01.07	Non-NTEP
Rice, LG Parboiled	CO155	0516	0023	1089	0000	1580	2065	2410	0123	1064	09.30.86	Customer Calibration
Rice, LG Rough (8-26%)	050210N	1212	3944	1320	4451	1900	2042	2608	9939	1057	08.01.07	NTEP
Rice, LG Rough (California)		0266	1759	1177	0909	1900	2065	2508	0292	1064	12.29.88	
Rice, LG Rough Parboiled	CO161	0093	3098	1215	2376	1900	2065	2008	0200	1064	11.03.87	Customer Calibration
Rice, Medium Brown	Special	2531	1328	1314	0000	2550	2038	1710	0295	1064	06.06.79	Customer Calibration
Rice, MG (8-28%)		1356	3636	1255	4179	1900	2053	2808	9933	1057	02.08.05	
Rice, MG <Arroz Gr Medio>		1367	3836	1284	4398	1900	2065	2810	0246	1064	07.23.86	Argentina
Rice, MG Brown (10-20%)	030315	2100	1333	1251	0164	2550	1072	2010	0216	1045	08.01.07	Non-NTEP
Rice, MG Milled (10-16%)	040331	2387	7751	1919	8002	2770	1061	1610	0345	1045	08.01.07	Non-NTEP
Rice, MG Milled Parboiled (10-14%)	030507	1454	0400	0057	0001	2460	1088	1410	1054	1045	08.01.07	Non-NTEP
Rice, MG Rough		1019	3229	1222	2562	1900	2065	2810	0226	1064	11.12.87	
Rice, MG Rough (8-30%)	070327N	1289	3953	1312	4493	1900	1849	3008	9920	1047	08.01.07	NTEP
Rice, MG Rough Etended Moisture Limits (8-26%)	AL005	1268	3953	1312	4493	1900	1849	2608	9945	1047	08.11.05	
Rice, Milled	CO248	0900	1070	1210	0000	2740	2065	2010	1860	1064	05.23.90	Customer Calibration
Rice, Milled M-7	CO155	3281	0702	0209	0000	2730	2065	1710	0277	1064	09.30.86	Customer Calibration
Rice, Milled Parboiled	CO155	4786	1843	1527	0000	2240	2065	1510	0964	1064	09.30.86	Customer Calibration
Rice, Milled Screenings (10-15%)	030417	0732	3804	1472	4000	2800	1054	1510	0295	1024	08.01.07	Non-NTEP
Rice, Paddy	CO248	2080	1170	1200	0000	1870	1090	3010	1743	1064	05.23.90	Customer Calibration
Rice, Paddy M-7	CO155	1109	3012	1179	2370	2100	2065	2710	0786	1064	09.30.86	Customer Calibration
Rice, Parboiled	CO141	0833	1075	1151	0000	1850	1090	2012	0291	1064	06.05.86	Customer Calibration
Rice, Parboiled Brown	CO155	2769	1421	1355	0000	2420	2065	1511	0819	1064	09.30.86	Customer Calibration
Rice, Pelde Brown	CO155	2787	1421	1355	0000	2420	2065	1812	0500	1064	09.30.86	Customer Calibration
Rice, Pelde Paddy	CO155	1010	1821	1156	2110	1860	2065	2710	0420	1064	09.30.86	Customer Calibration
Rice, Raw <Arroz Cru> (6-14%)		0162	0011	1019	0000	1240	0063	1406	0152	1054	06.08.05	Customer Calibration
Rice, Raw <Arroz Cru> (6-17%)		0167	1204	1055	0251	1245	2070	1706	0118	1054	03.14.05	Brazil
Rice, Raw <Ri Sone>		0602	1232	1129	0194	1880	1568	2907	0463	1074	03.18.91	djEurope-Italy
Rice, Rough	Special	2224	1355	1207	0000	1900	1090	1610	0201	1064	03.15.79	Customer Calibration
Rice, Second Head Milled (10-15%)	030417	0732	3804	1472	4000	2800	1054	1510	0295	1024	08.01.07	Non-NTEP
Rice, Second Head Milled Parboiled (10-14%)	030505	0429	1926	1244	2029	2800	1038	1410	0236	1024	08.01.07	Non-NTEP
Rice, SG and MG		1367	3836	1284	4398	1900	2065	2810	0246	1064	07.23.86	
Rice, SG Brown (10-18%)	030422	0443	5583	1561	6001	2550	1085	1810	1070	1045	08.01.07	Non-NTEP
Rice, SG Milled (10-16%)		0115	0157	1047	0001	2850	1056	1610	1088	1045	04.11.03	Non-NTEP
Rice, SG Rough		1354	3316	1197	2806	1900	2065	2810	0279	1064	04.17.03	
Rice, SG Rough (10-18%)		1352	3636	1255	4179	1900	2053	1810	0252	1047	04.13.00	
Rice, SG Rough (10-26%)	020327	1441	3846	1280	4455	1900	2058	2610	0233	1047	08.01.07	Non-NTEP
Rice, Steamed (15-25%)		0026	0203	1021	0000	2435	2049	2515	9969	1047	08.04.05	Customer Calibration

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Rice, Thai (8-35%)	CO438	0336	3170	1257	2361	1900	2047	3508	0281	1040	12.13.01	Customer Calibration
Rice, Vacuum Dried Paddy	Special	2038	1091	1223	0000	1950	2067	3425	0270	1064	03.15.79	Customer Calibration
Rice, Wild	CO140	0422	0017	1084	0000	2300	2065	2505	0204	1064	05.19.86	Customer Calibration
Rogge		0405	1305	1138	0390	2265	2068	2508	0608	1054	07.10.95	Flemish
Rye	CO322	0381	1305	1138	0390	2515	2068	2908	1369	1054	05.12.95	GMT II Canada
Rye (8-20%)	060322	0402	1305	1138	0390	2265	1074	2008	1312	1055	08.01.07	Non-NTEP
Rye (8-25%)		0405	1305	1138	0000	2355	2070	4508	0049	1054	05.01.91	djEurope-France
Rye (8-25%)		0398	1305	1138	0390	2265	2068	2508	0616	1054	03.17.04	djEurope-Austria
Rye (8-29%)		0386	1305	1138	0390	2515	2068	2908	1364	1054	06.25.92	Canada
Rye <Centeio>	CO299	3572	5095	1202	6247	2035	2068	2612	1322	1054	12.15.92	Brazil
Rye <Centeno>		0402	1305	1138	0390	2265	2068	2908	1300	1054	04.24.87	Argentina
Rye <Seigle>		0405	1305	1138	0390	2265	2068	2508	0608	1054	05.01.91	djEurope-France
Rye grass (6-22%)		1510	3062	1122	0398	2342	2068	2707	1684	1104	08.20.1930	djEurope-France
Safflower	CO322	1156	1503	1070	0737	1805	1599	2003	1894	1064	05.12.95	GMT II Canada
Safflower (3-20%)		1154	1503	1070	0737	1805	1599	2003	1896	1064	06.26.92	Canada
Safflower (California)		1175	1503	1070	0737	1735	1599	2003	1846	1064	05.11.83	
Safflower <Girasol Conf>		1179	1503	1070	0737	1735	1599	2003	1842	1064	04.11.83	Argentina
Safflower Seed (4-14%)	0000405	1690	3005	1093	2518	1605	1549	1404	1880	1057	08.01.07	Non-NTEP
Segala		0405	1305	1138	0390	2265	2068	2908	0604	1054	03.18.91	djEurope-France
Sesame (5-7%)		0888	1335	1139	0378	2305	1570	2508	1440	1064	06.06.1902	djEurope-France
Sorghum (8-24%)	080501N	0631	1935	1280	2006	2605	1060	2408	0266	1035	05.01.08	NTEP
Sorghum (8-24%)		0371	3981	1421	2575	1805	1550	2004	0351	1004	03.10.98	djEurope-France
Sorghum (8-25%)		0721	1086	1144	0023	2340	1572	2508	0967	1084	03.17.04	djEurope-Austria
Sorghum (8-28%)		0726	3823	1446	2977	2605	1065	2808	9999	1045	02.08.05	
Sorghum (8-32%)		0721	1086	1144	4009	1555	1550	2505	1081	1004	09.22.87	djEurope-France
Sorghum <Sorgho>		0721	1086	1144	0023	2340	1572	3208	0960	1084	05.01.91	djEurope-France
Sorghum <Sorgo>		0542	3312	1330	2471	2405	2057	2209	1024	1044	01.09.95	Argentina
Sorghum <Sorgo> (8-25%)		0721	1086	1144	0023	2340	1572	2508	0967	1084	05.01.91	djEurope-France
Soy Bran <farelo de soja> (6-13%)		1281	0661	0000	0000	1600	0570	1306	0120	1054	05.16.05	Brazil
Soybean	CO322	0106	1212	1061	0326	2395	1899	2508	0139	1105	05.16.95	GMT II Canada
Soybean Hulls (5-16%)	CO431	0084	0122	1010	0000	1735	1899	1605	0142	1085	09.14.01	Customer Calibration
Soybean Meal	CO230	0231	0022	1031	0000	2250	2070	1810	1888	1054	07.31.89	Australia
Soybean Meal (2-20%)		0000	0160	0000	0000	2215	2075	2002	0142	1087	03.24.03	Customer Calibration
Soybeans		1172	1502	1076	0764	2455	1899	2808	0159	1105	04.16.92	
Soybeans (6-26%)	050210N	1074	1506	1089	0727	2455	2074	2606	9916	1087	08.01.07	NTEP
Soybeans (6-36%)		1013	1339	1069	0517	2455	2075	3606	0165	1087	04.08.03	Brazil
Soybeans (7-25%)		1410	1999	1128	2414	2335	1390	2507	0168	1064	05.06.02	djEurope-France
Soybeans (8-25%)		1366	3191	1171	2626	2285	1875	2508	0119	1057	04.28.04	Canada
Soybeans <Soia>		1230	3061	1163	2411	2455	1899	2808	0165	1104	03.18.91	djEurope-Italy
Soybeans <Soja>		1372	1961	1131	2372	2336	1390	2706	0183	1064	05.01.91	djEurope-France
Soybeans <Soja>		1173	1502	1076	0764	2455	2089	2408	0181	1085	05.19.95	Argentina
Soybeans <Soja> (6-27%)		1372	1961	1131	2372	2336	1390	2706	0183	1064	03.17.04	djEurope-Austria
Soybeans <Soja> (7-28%)		1125	1672	1112	0940	2455	1899	2807	0132	1085	11.16.92	GMTII Brazil
Soybeans <Soya>		1385	1961	1131	2372	2336	1390	2706	0183	1051	03.18.91	djEurope-Germany

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Soybeans, Brazil (6-35%)	CO429	0137	1107	1048	0193	2455	2075	3506	0134	1087	12.01.00	Customer Calibration
Soybeans, Brazil Pelatized (10-18%)	CO429	5812	5382	1103	8090	2050	1370	1810	0027	1054	07.12.01	Customer Calibration
Soymeal (8-13%)		0211	0022	1031	0000	2250	2070	1308	1814	1054	08.04.04	Customer Calibration
Sugar Beet Seed (5-57%)		0165	0030	1010	0000	1601	4047	5705	2504	1034	07.23.02	Customer Calibration
Sugarbeet seed (5-15%)		0519	1092	1069	0000	1055	1550	1505	1670	1004	02.12.98	djEurope-France
Sunflower (6-23%)		1228	1557	1071	2249	2342	2068	2508	1486	1144	05.15.92	djEurope-France
Sunflower <Girasole>		1228	1557	1071	0817	1413	1580	2703	0893	1074	03.18.91	djEurope-Italy
Sunflower <Sonnenblume> (6-23%)		1203	1627	1084	0875	1442	1580	2306	0848	1074	03.17.04	djEurope-Austria
Sunflower Oil (2-32%)		1184	1376	1045	0590	1305	1575	3202	1704	1048	10.02.03	Customer Calibration
Sunflower Oil (6-14%)		1221	1557	1071	0624	2355	2070	3313	0056	1054	02.08.94	djEurope-France
Sunflower Oil (6-23%)		1548	1865	1083	2300	1293	1580	2306	0872	1074	10.14.03	djEurope
Sunflower Oil (7-22%)		1163	1433	1055	0650	1305	1599	2207	1761	1064	06.26.92	Canada
Sunflower Seed, oil-type (4-22%)	050208N	1144	1368	1048	0573	1305	1575	2204	9992	1048	08.01.07	NTEP
Sunflower, Confectionary (7-24%)		1116	1235	1030	0433	1085	1599	2407	1773	1064	06.26.92	Canada
Sunflower, Oil Type <Girasol>		1163	1433	1055	0650	1255	1599	2007	1714	1064	12.21.94	Argentina
Sunflower, Oil Type <Tournesol Oleique>		1221	1557	1071	0817	1413	1580	1406	0810	1074	02.08.94	djEurope-France
Sunflower, White Confectionary (7-14%)		3864	3654	1084	4867	0860	2042	1407	1719	1057	08.18.05	Customer Calibration
Tarwe		0385	1705	1209	0862	2342	2068	2508	0282	1074	07.10.95	Flemish
Tarwe, Harde		0195	3383	1296	2683	2365	2068	2508	0310	1094	07.10.95	Flemish
Tarwe, Zwarte		0688	1394	1188	0378	2305	1570	2508	1440	1064	07.10.95	Flemish
Titicale (10-25%)		0499	1749	1230	0869	2190	2553	2510	1534	1084	11.16.92	GMTII Brazil
Tobacco		0598	0286	1018	1423	0405	2599	2509	1304	1104	01.12.93	Argentina
Tobacco (9-20%)		0598	0286	1018	0556	2155	1550	2505	1830	1114	01.12.93	India
Tobacco, Finland	CO304	5049	3404	1038	4746	0595	2599	1810	1397	1104	02.04.93	Customer Calibration
Tobacco, Flue Cured (8-18%)	CO292	7889	5530	1054	8987	0535	2599	1808	1345	1104	09.08.92	
Tobacco, in process steamed (15-30%)	AL006	1073	1301	1045	0534	0635	2599	3015	1326	1104	01.17.05	Customer Calibration
Tobacco, Malasia	CO304	5971	5351	1082	8171	0575	2599	1910	1316	1104	02.04.93	Customer Calibration
Tobacco, Muratti	CO304	1092	1242	1032	0463	0595	2599	1708	1313	1104	02.04.93	Customer Calibration
Tomato (5-15%)		1454	1871	1103	0000	1930	1590	0705	1219	1054	02.12.98	Etats-Unis
Triticale (8-15%)	040330	0500	1898	1246	0998	2420	1074	1508	1548	1045	08.01.07	Non-NTEP
Triticale		0621	1041	1122	0000	2420	2553	2508	1580	1084	07.10.95	Flemish
Triticale		0410	1305	1138	0390	2265	2068	2208	0908	1049	03.18.91	djEurope-Germany
Triticale (10-25%)		0478	1749	1230	0869	2190	2553	2510	1534	1005	09.11.03	Brazil
Triticale (8-15%)		0500	1898	1246	0998	2420	1074	1508	1548	1045	03.30.04	
Triticale (8-25%)		0621	1041	1122	4690	1713	1380	1004	0872	1074	05.01.91	Africa
Triticale (9-24%)		0630	1050	1120	0000	2342	2068	2409	1543	1074	03.17.04	djEurope-Austria
Vetch (12-25%)		0177	0123	1034	0750	1716	1380	2105	2022	1074	05.01.91	Cameroon
Vetch <Vesce>		0177	0123	1034	0000	2342	2068	2512	1718	1074	05.01.91	djEurope-France
Vlas		1046	1032	0000	0146	1790	1590	2306	1233	1014	07.10.95	Flemish
Vlas, Olieachtig		0245	0036	1035	1028	2090	1570	1806	1294	1054	07.10.95	Flemish
Walnut, Ground (1-16%)		0132	1585	1116	0710	1605	2099	1601	1344	1054	08.10.79	
Walnut, Kernels (1-16%)		0148	0018	1021	0000	1500	2099	1601	1527	1054	03.24.80	
Walnut, Shells (1-16%)		0109	1662	1139	0859	1805	2099	2501	1404	1054	03.11.80	
Wheat (8-34%)		0091	0153	1025	0000	2505	2553	3408	0429	1082	09.08.04	Customer Calibration

GAC 2100 Grain Calibrations

last updated 05.01.08

<u>Grain</u>		<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Wheat (9-24%)		0591	1359	1181	0398	2341	2060	2409	1508	1084	03.17.04	djEurope-Austria
Wheat <Trigo> (10-25%)		0781	0809	1009	1995	2425	2577	2510	0483	1034	11.16.92	GMTII Brazil
Wheat <Weisen>		1069	1999	1209	2397	2345	2068	2508	0252	1064	03.18.91	djEurope-Germany
Wheat, Amber Durum	CO322	0848	1118	1174	0000	2705	2068	2107	0786	1034	05.12.95	GMT II Canada
Wheat, Amber Durum (7-21%)		0850	1118	1174	0000	2705	2068	2107	0784	1034	06.26.92	Canada
Wheat, Durum (6-20%)	080328N	0603	1533	1204	0549	2505	1861	2006	9939	1045	05.01.08	NTEP
Wheat, Durum (7-14%)		0201	3383	1296	2683	2365	2068	2508	0303	1094	03.17.04	djEurope-Austria
Wheat, Durum (7-21%)		0595	2019	0061	3204	2705	2068	2107	0720	1034	06.12.96	Canada
Wheat, Durum (8-25%)		0195	3383	1296	2069	1605	2099	3004	0801	1054	05.01.91	Israel
Wheat, Durum <Candial>		0440	3050	1274	2214	2365	2068	2007	0755	1035	12.21.94	Argentina
Wheat, Eastern Red	CO322	0563	1546	1208	0606	2550	2577	2006	0532	1044	05.15.95	GMT II Canada
Wheat, Eastern Red (6-20%)		0995	1178	1196	0000	2550	2577	2006	0593	1044	06.11.96	Canada
Wheat, Eastern White		0189	1719	1262	0700	2505	2570	2208	1132	1034	03.30.83	
Wheat, Eastern White (8-22%)		0796	1719	1262	0700	2505	2570	2208	1125	1034	07.14.96	Canada
Wheat, Eastern White <Trigo Blanco E>		0789	1719	1262	0700	2505	2570	2109	1132	1034		Argentina
Wheat, Flaked	CO142	0415	0047	1070	0000	7500	2577	2415	0584	1054	06.10.86	Customer Calibration
Wheat, Hard <Ble Dur>		0195	3383	1296	2683	2365	2068	2508	0310	1094	05.01.91	djEurope-France
Wheat, Hard <Grano Duro>		0195	3383	1296	2683	2365	2068	2908	0336	1064	03.18.91	djEurope-Italy
Wheat, Hard Red Spring	CO322	2134	1178	1231	0000	2525	2068	2007	0841	1044	05.12.95	GMT II Canada
Wheat, Hard Red Spring (6-22%)	080326N	0495	1664	1220	0766	2505	1074	2206	9975	1045	05.01.08	NTEP
Wheat, Hard Red Spring (7-20%)		2230	1244	1242	0000	2525	2068	2007	0866	1044	06.10.99	Canada
Wheat, Hard Red Spring <Trigo RDV>		0489	3303	1324	2480	2505	2068	2108	0876	1044	12.21.94	Argentina
Wheat, Hard Red Winter (6-22%)	060308N	0673	1716	1247	0738	2500	1074	2206	9948	1045	08.01.07	NTEP
Wheat, Hard Red Winter (Canada)	CO211	0439	3577	1368	2821	2500	2577	2006	0548	1054	07.12.88	Canada
Wheat, Hard Red Winter <Trigo RDI>		0435	3577	1368	2821	2500	1084	2008	0568	1044	05.19.95	Argentina
Wheat, Hard White (6-18%)	080331N	0778	1546	1230	0499	2500	0894	1806	9959	1045	05.01.08	NTEP
Wheat, Hard White (8-22%)	050208N	0610	1037	1124	1001	2500	1072	1606	9963	1045	02.08.05	Official GAC 2100 2006
Wheat, MIDDS (5-12%)	CO431	0785	1299	1105	0000	1015	2572	1205	1899	1064	12.15.90	Customer Calibration
Wheat, Midds (8-12%)		0778	1299	1105	0000	1015	2577	1208	0814	1064	09.19.03	Customer Calibration
Wheat, Red Spring (7-20%)		0141	0158	1042	0000	2685	2068	2007	0814	1044	06.26.92	Canada
Wheat, Red Winter (6-20%)		0419	3577	1368	2821	2750	2577	2006	0526	1044	06.26.92	Canada
Wheat, Soft (8-25%)		0385	1705	1209	2556	1155	1550	2206	1833	1004	05.01.91	Netherlands
Wheat, Soft <Ble Tendre>		0385	1705	1209	0862	2342	2068	2508	0282	1074	05.01.91	djEurope-France
Wheat, Soft <Grano Tenero>		0621	1041	1122	0000	2420	2553	2508	0207	1070	03.18.91	djEurope-Italy
Wheat, Soft Red Winter (8-22%)	070327N	0430	1936	1255	2091	2505	1068	2208	9996	1045	08.01.07	NTEP
Wheat, Soft Red Winter <Trigo RBl>		0513	3098	1295	2249	2505	2577	2208	0421	1034	12.21.94	Argentina
Wheat, Soft Rongotea	CO176	0514	3098	1295	2249	2505	2577	2508	0487	1064	05.12.87	Customer Calibration
Wheat, Soft White (6-22%)	070327N	0433	1572	1193	0678	2505	1073	2206	9948	1045	08.01.07	NTEP
Wheat, Soft White Spring	CO322	0775	1719	1262	0700	2675	2570	2208	1175	1034	05.12.95	GMT II Canada
Wheat, Soft White Spring (8-22%)		0780	1719	1262	0700	2675	2570	2208	1170	1034	06.26.92	Canada
Wheat, Soft Winter (8-25%)		0385	1705	1209	0862	2342	2068	2508	0282	1074	05.01.91	
Wheat, Western White		0186	1719	1262	0700	2505	2570	2208	1135	1034	03.30.83	
Wheat, Western White <Trigo Blanco W>		0786	1719	1262	0700	2505	2570	2008	1137	1034	01.09.95	Argentina
Wheat, White Flakes		1272	1568	1099	2050	1275	2580	2210	1753	1104	09.16.04	Customer Calibration

GAC 2100 Grain Calibrations

last updated 05.01.08

Grain

	<u>K1</u>	<u>K2</u>	<u>K3</u>	<u>K4</u>	<u>K5</u>	<u>K6</u>	<u>K7</u>	<u>K8</u>	<u>K9</u>	<u>Release Date</u>	
Whey	0277	1009	1045	0000	1190	2070	2005	1408	1054	08.08.83	Preliminary Constants 1984
Wikkezaad	0177	0123	1034	0000	2342	2068	2512	1718	1074	07.15.95	Flemish
Yeast (3-17%)	1607	3561	1200	4136	2110	2070	1703	1774	1104	01.09.06	Customer Calibration