

# CONTROLKING™



## VERSATILE

CONTROLKING IS VERSATILE, MAKING IT A PERFECT SOLUTION FOR ALMOST ANY APPLICATION. IT IS EASY TO CONFIGURE FOR ANY INSTALLATION—CHANGE THE TOTAL NUMBER OF JOYSTICKS AND CONTROL PROPORTIONAL OR “BANG-BANG” HYDRAULICS. AND, YOU CAN INSTALL IT WITH ANY BRAND OF HYDRAULIC VALVES.

## SELF-CONTAINED

CONTROLKING'S ALL-IN-ONE UNIT PROVIDES FOR FLEXIBILITY IN INSTALLATIONS WHILE REDUCING INSTALLATION LABOR AND GIVING YOU MORE ROOM IN THE CAB. AND, CONTROLKING FITS IN CABS OF ALL SIZES WITHOUT HIDING ANYTHING UNDER THE SEAT.

## DUAL AXIS OR SINGLE AXIS

CONTROLKING IS AVAILABLE IN BOTH DUAL- AND SINGLE-AXIS VERSIONS. DUAL-AXIS CONTROLLERS LET YOU MOVE THE JOYSTICK IN FOUR DIRECTIONS (PLOW UP, PLOW DOWN, LEFT, AND RIGHT). SINGLE-AXIS MODELS ALLOW YOU TO MOVE THE JOYSTICK UP AND DOWN AND HAVE A SAFETY SWITCH THAT PREVENTS ACCIDENTAL ACTIVATION.

## FEATHERING

CONTROLKING LETS YOU CALIBRATE THE MINIMUM AND MAXIMUM FLOW RATES FOR UNLIMITED PWM OUTPUT SIGNAL ADJUSTMENT, GIVING YOU “FEATHERING” CONTROL OF YOUR HYDRAULIC SYSTEM.

## AUTOMATIC FLOAT CONTROL

THE DUAL-AXIS CONTROLKING COMES WITH FLOAT MODE TO KEEP THE PLOW IN CONTACT WITH THE ROAD WHILE AUTOMATICALLY FOLLOWING THE CONTOUR OF THE ROAD.

## ELECTROMAGNETIC INTERFERENCE (EMI) AND ELECTROSTATIC DISCHARGE (ESD) PROTECTED

DICKEY-JOHN ENGINEERED CONTROLKING TO PREVENT DANGEROUS INTERFERENCE FROM ELECTROMAGNETIC WAVES FROM CELL PHONES, TWO-WAY RADIO TOWERS, AND OTHER SOURCES. AND, CONTROLKING'S DESIGN REDUCES ITS SUSCEPTIBILITY TO STATIC ELECTRICITY, WHICH CAN SEVERELY DAMAGE ELECTRONIC EQUIPMENT.

## BACKED BY THE POWER OF DICKEY-JOHN

WHEN YOU BUY CONTROLKING, YOU GET ALL THIS, PLUS THE DEPENDABILITY AND RELIABILITY YOU EXPECT FROM DICKEY-JOHN PRODUCTS. DICKEY-JOHN'S ADVANCED TECHNOLOGY AND SUPERIOR ELECTRONICS ARE BACKED BY A TEAM OF EXPERT IN-HOUSE MECHANICAL, ELECTRICAL, SOFTWARE, AND TEST ENGINEERS. AND, WE MANUFACTURE ALL OF OUR PRODUCTS, ENSURING TOTAL QUALITY CONTROL—WE'RE ISO 9001 CERTIFIED.

**THE WORLD'S  
MOST CONVENIENT  
CONTROLLER,  
CONTROLKING™  
COMBINES JOYSTICK  
AND ELECTRONICS  
INTO ONE UNIT.**

**ControlKING®**

5200 DICKEY-JOHN ROAD  
AUBURN, IL 62615  
WWW.DICKEY-JOHN.COM

TOLL FREE: 800-637-2952  
PHONE: 217-438-3371  
FAX: 217-438-6012



**DICKEY-john®**  
CORPORATION

©2005 DICKEY-JOHN CORPORATION  
11071-0302  
200502

**WE'RE OUT HERE**